

Personal Protective Equipment Policy

Personal protective equipment (PPE) is made readily available in the laboratories and based on laboratory hazard assessments, are to be used by all faculty, students, and staff. The University conducts regular laboratory hazard assessments in accordance with OSHA 29 CFR 1910.1200. The *Personal Protective Equipment Assessment Guide* in Appendix B to Subpart I, *Compliance Guidelines for Hazard Assessment and Personal Protective Equipment Selection*, is also to provide appropriate PPE training visitors.

General laboratory hazard assessments are conducted annually by the Environmental Health and Safety Office (EHSO) and include a survey of individual laboratory. Laboratory surveys include consideration of the following basic hazard categories:

- Chemical
- Heat / Flammability
- Particulates
- Impact
- Penetration
- Compression (roll-over)
- Light (optical) radiation

Laboratory hazard assessments include a walk through and evaluation of chemical, equipment, and process hazards present in each laboratory. Consideration of the chemical hazards present is performed through (1) an annual inventory of the chemicals in each laboratory and (2) daily monitoring of all chemical orders and chemical transfers and inquiries to each laboratory. Material Safety Data Sheet (MSDS) review of the chemicals present in each laboratory is conducted annually both at the time of chemical receipt, in compliance with the PPE analysis and selection process. Documentation and communication of the laboratory hazard assessments is achieved through hazard identification, emergency contact signage posted at the entrance to each laboratory (See Appendix F for example signage).

Experiment specific laboratory hazard assessments for academic and/or research work are conducted as necessary by faculty and laboratory instructors or, by request, in collaboration with the EHSO. Experiment specific laboratory hazard assessments involve the communication from the laboratory instructors to increase or decrease the general laboratory hazard assessment. PPE requirements based on experiment specific protocols and associated safety considerations. For submitted laboratory hazard assessments are to be documented, sent to the EHSO for record keeping, and clearly communicated to all experiment participants. Faculty's for returning laboratories deviations from the general laboratory hazard assessment PPE requirements can be made through discussion with the faculty supervisor based on the specific procedures being used. In addition, EHSO will facilitate the appropriate levels of PPE across the range of experimental procedures, as is manifested in the research setting.

Eye and Face Protection

Eye and face protection are to be worn by all persons whenever any person is in a laboratory or conducting an activity that involves potential eye and face hazards. Activities that present potential eye and face hazards include, but are not limited to, work involving the following:

- hazardous dust
- flying particles
- hot solids, liquids, or molten metals
- milling, sawing, cutting, shaping, cutting, or stamping of any solid materials
- heat treatment, tempering, or kiln firing of any material or component
- gas or electric welding
- potentially injurious light radiation

All protective eyewear in a laboratory must meet the ANSI Z87.1-2003 standard. Laboratory eyewear that outputs must also meet the ANSI Z87.1-2007 standard. The below explanatory information and Appendix B (ANSI Z87.1-2003 Eye Protection and Facial Protection Chart) and the Face Protection Chart (in the Face Protection Chart) are intended to aid in identifying and selecting eye and face protection to match the hazard source.

Safety Glasses

Safety glasses provide eye protection from moderate impact and particle hazards associated with grinding, sawing, scaling, broken glass, minor chemical splashes, etc. Side protectors are required when there is a hazard from flying objects. Alternative safety glasses meeting the ANSI Z87.1-2003 standard provide adequate splash protection; splash goggles are an approved alternative for additional eye protection from chemicals.

Regular prescription eyeglasses (with or without side shields) and contact lenses are not a substitution for safety glasses or splash goggles. Contact lenses should never be worn in the laboratory environment. Use of contact lenses in the laboratory may be approved by the laboratory supervisor prior to commencing any activity involving a chemical hazard. Faculty and staff who wear prescription eyeglasses or contact lenses should consider obtaining a pair of prescription safety glasses. Faculty and staff may obtain prescription safety glasses through the College Prescription Safety Glasses Fund, by contacting the CEMC. Students, faculty, and staff who do not obtain prescription safety glasses are to wear safety glasses (for impact hazards) or safety goggles (for optical hazards), designed to go over their prescription glasses.

Splash Goggles

Splash goggles provide adequate eye protection from hazards including potential chemical splash, use of concentrated corrosive material, and bulk chemical transfer. Goggles are to

available with clear or tinted lenses for protection against vibration or non-ventilated environments with chemicals. Be aware that goggles designed for wood working are not suitable for welding operations. Welding goggles can be identified by the numerous small holes throughout the face piece for the evaporation of a splash, the penetration of chemicals to create numerous small holes resulting in a chemical exposure to the face.

Welder / Chipper Goggles

Welder goggles provide protection from sparks, metal spatter, etc., by filtering out radiant energy. Lens are impact resistant and are available in graduated lens shades depending on the nature of the work. Minimum protective shade numbers based on the type of welding operations can be found can be found in the OSHA 30 CFR 1910.123 Welding Face Protection standard (see section below).

Filter Lenses for Protection Against Radiant Energy

Welding Operations	Electrode size (inches)	Arc Current (amps)	Minimum Protective Shade
Shielded metal arc	<3/32	<60	7
	3/32 to 5/32	60 to 160	8
	4/32 to 1/4	160 to 250	10
	>1/8	250 to 550	11
Gas metal arc and flux cored arc welding		<60	7
		60 to 160	10
		160 to 250	10
		250 to 550	10
Gas Tungsten arc welding	08		
		50 to 150	8
		100 to 300	10
Air carbon arc cutting	(light)	<500	10
	(heavy)	500 to 1000	11
Plasma arc welding		20 to 100	8
		100 to 400	10
		400 to 800	11
Plasma arc cutting	(light)	<300	
	(medium)	300 to 400	
	(heavy)	400 to 800	
Torch brazing			3
Torch soldering			2
Carbon arc welding			1A
Welding Operations	Plate thickness (inches)	Plate thickness (mm)	Minimum* Protective Shade
Gas welding (light)			
Gas welding (medium)	1/8 to 1/4	3.2 to 12.7 mm	5
Gas welding (heavy)	> 1/2"	> 12.7"	6
Oxygen cutting (light)	<1	> 25	3
Oxygen cutting (medium)	1 to 6	25 to 150	4
Oxygen cutting (heavy)	> 6	> 150	5

- * As a rule of thumb, start with a minimum shade number one lighter shade that gives sufficient view of the weld zone withoutargon. In oxyfuel gas welding or cutting where the torch produces a high yellow light, it is desirable to use a filter lens that absorbs the yellow emission in the white light of the oxyfuel operation.

Face Shields

Face shields provide additional protection to the eyes and face and can be used in combination with safety glasses or splash goggles. Face shields consist of an adjustable headgear and a face shield with either tinted or clear lenses, or a mesh wire screen. Face shields should be used in operations when the entire face needs protection from flying particles, metal sparks, dust, mud, cryogens, or chemical/biological splashes. Face shields are a substitute for appropriate eyewear and should always be worn in conjunction with a primary mask or protective equipment such as safety glasses or goggles.

Welding Shields

Welding shields are similar to face shields in that they provide additional protection from radiant light, flying sparks, metal splatter, and slag chips encountered during welding, brazing, soldering, resistance welding, bare or shielded electric arc welding, and oxyacetylene welding and cutting operations. Equipment fitted with appropriate filters and lenses are to be used to protect against light radiation. Tinted and shaded lenses are not filter lenses unless they are marked or clearly identified as such.

Laser Eye Protection

A single pair of safety glasses is not available for protection from all laser outputs. The type of eye protection required for laser operation is dependent on the spectral frequency and specific wavelength of the laser source. Consulting Cole's Guide to Safety in Research Laboratories and Guidance on the EHSQ for additional guidance on laser PPE selection.

Hand Protection

Gloves are to be used when handling hazardous chemicals in the laboratories. Typically, the requirements of the general laboratory hazard assessment should be followed. However, deviations may be made as outlined in the paragraph on experiment specific laboratory hazard assessments. EHSO can provide guidance on appropriate hand protection in instructions to researchers. It should be noted that no one glove material that protects against all chemicals. It is important that the appropriate glove is used when handling specific chemicals. Consult chemical compatibility charts, MSDS, and protective equipment manufacturer resources to aid in the selection of the proper glove protection level based on the chemicals being handled. (Note: see Appendix C for a university approved manufacturer chemical compatibility chart). In situations involving extremely hazardous chemicals, double gloves in combination with sleeve protectors and/or chemically resistant PPE are recommended. The thin latex, vinyl, or nitrile gloves popular for their dexterity, are not appropriate for highly toxic or corrosive chemicals. Gloves should always be inspected before use and replaced immediately if they are contaminated or torn. Gloves must be removed before handling telephones.

door knobs, desks, computers, etc.). This shall also include leaving the laboratory, with an exception being made for persons actively transporting chemical / biological hazard material between labs. Persons transporting chemicals should either have a second person available to open / close doors & storerooms, or use glove boxes. If using glove boxes, gloves must be worn at all times when handling chemical material. Glove protection is not required during the transport of chemicals in a lab cart, so long as the materials are secondary contained.

Colgate practices "Universal Precautions" for glove disposal. In practical terms, this means that ALL gloves will be treated as if they are contaminated (i.e., for infectious purposes) there will be no differentiation of contamination. This includes gloves used for general laboratory work, personal protection, self-disposal receptacles, trash, art, science store, and other horticultural activities. Any glove waste is disposed of as infectious waste. The Universal Precaution glove disposal policy minimizes glove waste, increases overall efficiency, and prevents cross-contamination of contaminated gloves with non-hazardous waste products. Pathology-related or custodial chemical contact - it should be noted that classroom, clinical, and research gloves contaminated with biological waste should be separated from gloves contaminated with chemical waste. Biological waste should be placed in either autoclaved plastic bags or in contaminated glove bags sent for disposal via the waste management system.

Protective Clothing

Lab coats, lab coats, aprons prevent skin contact exposure by creating a physical barrier between the hazard and the laboratory user. They should be clean, dry, and fit the extremities.

Lab Coats

Lab coats are to be used when handling hazardous chemicals in the laboratory. Typically, the requirements of the general laboratory hazard assessment should be followed. However, deviations may be made as outlined in the paragraph on experiment-specific laboratory hazard assessments. EHSC staff provide guidance on appropriate lab coats for specific laboratory settings. Faculty, staff, and student lab coats are procured and maintained by the University. Colgate's University's lab coats have the following protective qualities:

- Flame resistant fabric
- High tensile strength thread material
- NFPA 70E, HRC 3 compliant
- Arc Rated to 9 cal/cm²
- Thermal and electrical arc hazard rated to ASTM F1506-152A standard
- Covered zipper span front for quick and safe garment removal
- Covered zipper span pants to prevent garment interference during chemical handling / experimentation work
- Light weight (1.9 oz.)

- 42 inches in length for maximum skin exposure protection

Lab coats are maintained by each department individually, when necessary, through EHSO. Lab coats must be cleaned by a qualified commercial laundry service provider at the end of the summer. Summer is typically defined as any month in which temperatures exceed 70 degrees. Additional cleaning will be coordinated by the EHSO as necessary, upon request. In the event a lab coat becomes contaminated, or deteriorated, damaged, or torn, contact the scheduled individual for cleaning, contact the EHSO for assistance, or drop off to the laundry.

Lab Apron

Plastic or rubber lab aprons provide additional protection from skin contact exposure to chemicals, especially when working with flammable hazards and corrosive liquids. Lab aprons do not protect the user's extremities and should be used as an additional layer of protection, not a substitute, for a lab coat.

CAUTION


AUTHORIZED
PERSONNEL ONLY

This room contains hazardous materials.

In case of emergency

DIAL 911

From cell phones 315-228-7911.



RESPONSIBLE PERSON: Dan Gugan



EMERGENCY CONTACT: Dan Gugan/Michael Hayes

TELEPHONE:

315-865-2550 / 315-287-3591

LOCATION:

McGregory Hall, Chemical Bunker #3



APPENDIX B

ANSI Z87.1-2003 Occupational Eye and Face Protection Devices Selection Chart

APPENDIX C

Ansell 8th Edition Glove Chemical Resistance Guide

Penetration/Degradation Guide for Ansell Gloves

EDITIN	The letter in each column provides an overview for each type of colored code degradation icon.
A	The letter in each colored square is very suited for application under approval of the relevant authority.
B	With the help of the yellow transparent film, the adhesive can be applied directly onto the skin.
C	According to the properties of the adhesive, it is suitable for sensitive skin.
D	Red indicates that the adhesive is highly irritant.
E	Special features are highlighted in this color.
F	Gray indicates that the adhesive is not yet available.

